

# Packaging MDL Specimens for FedEx Pick-up.



**Insert labeled vial into mailer.**

**Be sure to include a completed test requisition form for each specimen in the front pocket of the biohazard bag.**



**Insert the mailer into biohazard bag.**



**Remove FedEx receipt inside Lab Pack for your records.**



**Don't forget to seal the Lab pack!**

**Insert sealed biohazard bag into the prepaid FedEx Lab Pack envelope. One Lab Pack will accommodate 6-7 Styrofoam containers.**



**Verify that a preaddressed airbill is attached to ensure proper delivery.**



# Packaging MDL Specimens for FedEx Pick-up.

# 1

**Insert labeled vial into mailer.**



**Insert the mailer into biohazard bag.**

**Be sure to include a completed test requisition form for each specimen in the front pocket of the biohazard bag.**



# 3

**Insert sealed biohazard bag into the prepaid FedEx Lab Pack envelope. One Lab Pack will accommodate 6-7 Styrofoam containers.**



**Remove FedEx receipt inside Lab Pack for your records.**

**Don't forget to seal the Lab pack!**

**Verify that a preaddressed airbill is attached to ensure proper delivery.**

